





BOOTH & Co.

ENGLAND



This instruction booklet covers model:

- BC-AXB-120-CP
- BC-AXB-120-BN
- BC-AXB-220-CP
- BC-AXB-220-BN



VADO
Wedmore Road, Cheddar,
Somerset, England BS27 3EB
tel 01934 744466
fax 01934 744345
www.vado.com
sales@vado.com

AXBRIDGE

BC-AXB-120-CP, BC-AXB-120-BN
BC-AXB-220-CP, BC-AXB-220-BN
INSTALLATION GUIDE

Version 1, 1-5-19

BOOTH & Co.
ENGLAND

Important - please read

Please read these instructions carefully before starting installation and keep for future reference.

Remove all packaging and check the product for missing parts or damage before starting installation.

Any alterations made to this product and fittings may infringe water regulations and will invalidate the guarantee.

The installation must comply with all Local/National Water Supply Authority Regulations/Byelaws and Building and Plumbing Regulations.

To be installed in accordance with BS EN806.

We strongly recommend that you use a qualified and registered plumber.

General installation

This fitting is a mixing device and therefore water supplies should be reasonably balanced.

When installed, the fitting must comply with the requirements of the Water Supply (Water Fittings) Regulations 1999 and Scottish Byelaws 2004.

For further information, contact the Water Regulations department of your local water supplier (see the WRAS website www.wras.co.uk for details) or the Water Regulations Advisory Scheme by email (info@wras.co.uk) or telephone: 01495848454.

Before making any inlet pipe connections, all supply pipes MUST be thoroughly flushed to remove debris. Failure to do so could result in damage or low flow from the mixer unit. Water Supply (Water Fittings) Regulations 1999 Schedule 2 Section 13.

The fitting of isolating valves to the inlet feeds is advised for ease of maintenance.

Please take great care when installing this mixer not to damage its surface.

Please note if installing in an enclosed environment, access should be left for servicing and maintenance. No costs relating to inadequate access can be accepted.

Operating Specifications

Operating Pressure


Minimum operating pressure 1 bar

Maximum operating pressure 5 bar


Contents of Packaging




Installation guide &
User manual




Handset



Handset holder



Covers with O-rings x 2




Connectors x2




Washer/filters x 2



Screws & wall plugs x 8





Mixer body




Shower hose
with x 2 washers

Contents of Packaging


Cross handle option OR Lever handle option




Dimensions - traditional handles





Dimensions - lever handles




Installation - Quick guide



Installation - Quick guide




Installation



Installation - handles

The handles can be fitted before or after the main installation. For illustrative purposes only the handles are being fitted before the tap installation. Please follow the same procedure to fit the handles after the tap has been installed.

For illustrative purposes only the cross handle is shown. The same procedure applies to install the lever handle.



Installing the handles

Remove cover nut and valve from the tap body, and then remove the lock nut from the valve. They should only be hand tight. See Fig. 1

Screw the valve back into the tap body. Place a handle onto splines and using light force only turn the handle clockwise until you feel a noticeable resistance when the base of valve touches down on the body of the tap.

Turn the handle so the valve is in the closed position, then remove the handle and refit back onto the spline so it is as square as possible (do not worry if it is not perfectly aligned at this stage).



Without forcing the handle, adjust the handle and the valve together so that the handle is perfectly straight making sure you do not unscrew the valve by more than 20°. Should you do so you will need to go back to the beginning of this section and start again.

Test the action of the handle and valve making sure that the handle is perfectly straight in the off position.

Remove the handle. See Fig. 2

Lever handle

The lever on the handle should point down when in the off position.



Installation - handles

Place the lock nut over the valve and screw down. Use a torque wrench to tighten the nut down to 20Nm. See Fig. 3

Screw the cover nut onto the valve, hand tight only.

Carefully slide the handle onto the splines of the valve with the handle pointing in the correct position.




See Fig. 4

Finally secure the handle in position.

Place the lock washer onto the screw and down through the handle, tighten using a cross head screwdriver.

Push on the handle cover.


See Fig. 5




Installation

Prepare the wall with 2 copper pipes at 180mm centres. Connect the water supply to the inlet pipes. The hot water should be connected to the left hand pipe.


Flush through the pipe work to remove any debris.



Temporarily screw both quick fit connectors onto the valve.




Position the valve and connectors over the pipes, use a level across the flats of the connectors making sure they are level. Mark the position of the 4 screw holes in each connector.



Warning! Please check for any hidden cables and pipes before drilling holes in the wall.



Remove the connectors from the valve. Remove the nut and olive from the connector. Drill the 4 marked holes to a suitable depth for the wall plugs and secure with supplied screws. Repeat for the other connector.



Installation

Slide on the olive, screw on and tighten the nut.

Before installation flush through the pipe work to ensure removal of debris, turn off the water supply.




Slide the covers over each connector. Place a rubber filter/washer in each of the locking nuts on the valve and screw onto the connectors.

Installation

Carefully screw the handset holder onto the valve. Make sure that it is in the correct position before tightening e.g. parallel with the wall.

Be careful not to damage the surface, do not over tighten.




Handset

Place one of the rubber washers into the cone end of the hose and screw to the Handset.

Place the handset onto the holder.

Mixer

Place the other rubber washer into the nut end of the hose and attach it to the mixer outlet.



Notes