




where inspiration flows

SAFARI




Installation Guide
Extended mono basin mixer


This instruction booklet covers these models:

SAF-100E, SAF-200E
(All finish options)

SAF-100E
SAF-200E



SAF-100E



SAF-200E

Vado
Wedmore Road, Cheddar, Somerset, England BS27 3EB
tel 01934 744466. fax 01934 744345
aftersales@vado.com
www.vado.com



Important - Please Read

Please read these instructions carefully before starting installation and keep for future reference.

Remove all packaging and check the product for missing parts or damage before starting installation.

Any alterations made to this product and fittings may infringe water regulations and will invalidate the guarantee.

The installation must comply with all Local/National Water Supply Authority Regulations/Byelaws and Building and Plumbing Regulations. To be installed in accordance with BS EN806.

We strongly recommend that you use a qualified and registered plumber.

General Installation

This fitting is a mixing device and therefore water supplies should be reasonably balanced.

When installed, the fitting must comply with the requirements of the Water Supply (Water Fittings) Regulations 1999 and Scottish Byelaws 2004.

For further information, contact the Water Regulations department of your local water supplier (see the WRAS website www.wras.co.uk for details) or the Water Regulations Advisory Scheme by email (info@wras.co.uk) or telephone: 01495848454.

Before making any inlet pipe connections, all supply pipes MUST be thoroughly flushed to remove debris. Failure to do so could result in damage or low flow from the mixer unit. Water Supply (Water Fittings) Regulations 1999 Schedule 2 Section 13.

The fitting of isolating valves to the inlet feeds is advised for ease of maintenance.

Please take great care when installing this mixer not to damage its surface.

Please note if installing in an enclosed environment, access should be left for servicing and maintenance. No costs relating to inadequate access can be accepted.

Please note: installation for the SAF-200E is shown throughout this guide, please follow the same instructions to install the SAF-100E.

Operating Specifications


Operating Pressure

Minimum operating pressure **1 bar ***

Maximum operating pressure **5 bar**

*** 0.2 bar** if using the supplied flow straightener

Contents of Packaging



Mixer body
to suit your model
(SAF-200E shown)



Installation guide & User manual

FIXING KIT




Rubber washer



Metal washer



Ring nut




Flexible hoses with washers



Base ring with O-ring

Dimensions - SAF-100E



Dimensions - SAF-200E

