

VADO

Wedmore Road, Cheddar, Somerset, England BS273EB tel 01934 744466 fax 01934 744345 www.vado.com sales@vado.com

Slide rail kit



Version 2, 1-3-21

INSTALLATION GUIDE

Important - please read

Please read these instructions carefully before starting installation and keep for future reference.

Remove all packaging and check the product for missing parts or damage before starting installation.

Any alterations made to this product and fittings may infringe water regulations and will invalidate the guarantee.

The installation must comply with all Local/National Water Supply Authority Regulations/Byelaws and Building and Plumbing Regulations. To be installed in accordance with BS EN806.

We strongly recommend that you use a qualified and registered plumber.

General installation

When installed, the fitting must comply with the requirements of the Water Supply (Water Fittings) Regulations 1999 and Scottish Byelaws 2004.

For further information, contact the Water Regulations department of your local water supplier (see the WRAS website www.wras.co.uk for details) or the Water Regulations Advisory Scheme by email (info@wras.co.uk) or telephone: 01495848454.

Please take great care when installing this product not to damage its surface.

Please note if installing in an enclosed environment, access should be left for servicing and maintenance. No costs relating to inadequate access can be accepted.

Guarantee

All VADO products come with a 2 year guarantee as standard. Within this guarantee period VADO will provide replacement parts and any labour **[SEE NOTE 1]** needed to complete the product repair.

This standard guarantee may be extended by registering your product to give the following guarantee periods, once registered:

Brassware products from the Individual by VADO collection have a 15 year guarantee (2 years parts and labour plus 13 years parts only).

VADO Sensori SmartTouch and SmartDial products have a 5 year guarantee (parts and labour). VADO Identity and i-tech products have a 5 year guarantee (2 year parts and labour plus 3 years parts only).

All other VADO products have a 3 year guarantee (2 years parts and labour plus 1 year parts only) **[SEE NOTE 2]**.

Guarantee Conditions

Our products are guaranteed against manufacturing defects from the date of purchase until the expiry of the relevant guarantee period shown above.

The guarantee is only valid if:

•The product has been installed, used and maintained in accordance with VADO's instructions and subjected to normal use only.

•The defect is not due to use of an unsuitable or inadequate water or power supply.

•The defect is not due to accident, misuse, neglect or incorrect/inappropriate repair (other than by VADO or VADO authorised agents) or damage caused by foreign objects or substances.

•The extended guarantee is only available if you have completed the Guarantee Registration Process.

This can be done via the VADO website or via phone to our aftersales team.

Registration must be completed within 6 months from date of purchase. Under the extended guarantee period VADO will, at its option, offer to supply any replacement

product (or component part) assessed to be defective **[SEE NOTE 3]**.

The guarantee (whether standard or extended) is non-transferable to any subsequent owner. All claims under the guarantee should be notified in the first instance to our Aftersales

department, contact details below, this must be done no later than the last day of the relevant guarantee period.

All claims must be accompanied by proof of purchase (sales receipt or delivery note) from an official VADO dealer.

The guarantee does not extend to any consequential loss or damage.

After repair or replacement, the relevant guarantee period will be calculated from the original date of purchase.

VADO operates a policy of continuous product development and therefore reserves the right to change the product, packaging and documentation specifications without notice. E&OE. **NOTES:**

[1] Labour via our engineer network is only available in the UK. Attendance by a VADO engineer or sub-contract engineer will be under our standard terms and conditions.

[2] VADO spare parts and shower hoses are under a parts only guarantee.

[3] VADO reserves the right to charge in advance for a product (or replacement part) pending collection and investigation (at VADO expense) to confirm a defect is due to a manufacturing issue.

If a defect is found the charge will be refunded or cancelled.


This guarantee is in addition to and does not affect your statutory rights as a consumer. Tel: 01934 745163

Email: aftersales@vado.com


Cleaning instructions

The physical vapor deposition coating on this product is finished to the highest standard. Due care needs to be taken to ensure the appearance is retained. We recommend cleaning all products with a soft damp cloth ONLY and advise strongly against the use of all aggressive/corrosive cleaning products i.e. powders and liquids. If these instructions are not followed, this may invalidate your guarantee in the event of a problem occurring.

Contents of Packaging




Shower hose with 2 washers



Operation

The holder can be repositioned by releasing the handle and sliding up and down.

Adjust the angle of the handset to the required position.




Hose connection

Handset


Place one of the rubber washers into the cone end of the hose and screw to the handset.


Outlet


Place the second rubber washer into the nut end of the hose and attach it to the mixer outlet.





Quick guide














Installation


Before you start the installation you will need to remove the mount blocks from both brackets. Using the supplied hex key release the grub screw on the bracket and remove the mounting block. Note the position of the notch (**Fig 1**).


Should you choose to adjust the height of the mounting brackets you can release the screw within the bracket, adjust the bracket by sliding up/down to desired position then retighten the screw **(Fig 2)**.


Position the rail on the wall, bearing in mind the different heights of people likely to use the shower.

Make sure the riser rail is vertical using a level. Mark the wall to indicate the position of both brackets **(Fig 3)**.

Remove the riser rail.








Installation

Place the mounting block in the centre of the marked bracket position. Mark the centre of the hole. Repeat for the other block **(Fig 1)**.



Using a suitable 6mm masonry drill bit for the wall plug, drill the wall at the centre of the 2 marked positions.

Fix the blocks in position using the supplied wall plugs and screws make sure that the notch is at the top on the top bracket and opposite position at the bottom **(Fig 2)**.

Refit the riser assembly by placing the brackets onto the mounting blocks and secure by tightening the grub screw with the supplied hex key (**Fig 3**).

