Guarantee

All VADO products come with a 2 year guarantee as standard. Within this guarantee period VADO will provide replacement parts and any labour [SEE NOTE 1, GUARANTEE CONDITIONS] needed to complete the product repair.

This standard guarantee may be extended by registering your product to give the following quarantee periods, once registered:

Brassware products from the Individual by VADO collection have a 15 year guarantee (2 years parts and labour plus 13 years parts only).

VADO chromed brassware and stainless steel products have a 12 year guarantee (2 years parts and labour plus 10 years parts supply only).

VADO Sensori SmartDial and SmartTouch products have a 5 year guarantee (parts and labour). VADO Identity and I-Tech products have a 5 year guarantee (2 year parts and labour plus 3 years parts supply only).

All other VADO products have a 3 year guarantee [2 years parts and labour plus 1 year parts supply only] [SEE NOTE 2, GUARANTEE CONDITIONS].

VADO electric showers have a 2 years parts and labour guarantee.

Guarantee Conditions

Our products are guaranteed against manufacturing defects from the date of purchase until the expiry of the relevant guarantee period shown above.

The guarantee is only valid if:

- 1. The product has been installed, used and maintained (maintenance guidelines can be viewed here) in accordance with VADO's instructions and subjected to normal use only.
- 2. The defect is not due to use of an unsuitable or inadequate water or power supply.
- 3. The defect is not due to accident, misuse, neglect or incorrect/inappropriate repair (other than by VADO or VADO authorised agents) or damage caused by foreign objects or substances.
- 4. The extended guarantee is only available if you have completed the Guarantee Registration Process. This can be done via the VADO website or via phone to our aftersales team.

Registration must be completed within 6 months from date of purchase.

Under the extended guarantee period VADO will, at its option, offer to supply any replacement product (or component part) assessed to be defective **[SEE NOTE 3]**.

The guarantee (whether standard or extended) is non-transferable to any subsequent owner. All claims under the guarantee should be notified in the first instance to our Aftersales department, contact details below, this must be done no later than the last day of the relevant guarantee period. All claims must be accompanied by proof of purchase (sales receipt or delivery note) from an official VADO dealer.

The guarantee does not extend to any consequential loss or damage.

After repair or replacement, the relevant guarantee period will be calculated from the original date of purchase.

VADO operates a policy of continuous product development and therefore reserves the right to change the product, packaging and documentation specifications without notice.

NOTES:

[1] Labour via our engineer network is only available in the UK. Attendance by a VADO engineer or sub-contract engineer will be under our standard terms and conditions.

[2] VADO spare parts and shower hoses are under a parts only guarantee.

[3] VADO reserves the right to charge in advance for a product (or replacement part) pending collection and investigation (at VADO expense) to confirm a defect is due to a manufacturing issue. If a defect is found the charge will be refunded or cancelled.

This guarantee is in addition to and does not affect your statutory rights as a consumer. Tel: 01934 745163

Email: aftersales@vado.com



INFRA-RED SPOUT MONO BASIN MIXER USER GUIDE



Welcome

Thank you for selecting Individual by VADO.


Each timeless finish has been tailored to inspire your individual style, ready for you to create a contemporary look that will stand the test of time.

Coupled with our leading 15 year guarantee, this premium product has passed through stringent quality assurance processes to allow you to complete your look with confidence.

Our outstanding customer service, large scale development support and prestigious project history has ensured a globally trusted reputation. For any technical or operation queries, please contact our experienced Aftersales team on 01934 745 163.

VADO, Wedmore Road, Cheddar, Somerset, England BS27 3EB tel 01934 744466. fax 01934 744345 aftersales@vado.com

Battery replacement



Undo the screw on the top and remove the lid.

Remove the 4 batteries


Insert the 4 replacement batteries according to the diagram in the bottom of the base.

Replace the lid making sure that the 2 springs are orientated to match the negative ends of 2 batteries. Place the battery case back into the compartment, fit the cover and replace the 4 screws.

Resetting

Hold down the red Reset button for 3 seconds and wait for 20 seconds before the sensor range can be reset, enabling the sensor to learn the IR distance to the sink.

Battery replacement



The unit is supplied with a battery backup, should the mains supply fail and the tap still will not function then the batteries may need replacing.

Remove the 4 screws retaining the cover and pull off, pull out the battery case (see above).

Please read

This appliance can be used by children aged 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved.

Children shall not play with the appliance.

Cleaning and user maintenance shall not be made by children without supervision.

Detachable hose-sets for the connection of appliances to the water mains shall comply with IEC 61770.

6

Cleaning instructions:

The physical vapor deposition coating on this product is finished to the highest standard. Due care needs to be taken to ensure the appearance is retained. We recommend cleaning all products with a soft damp cloth ONLY and advise strongly against the use of all aggressive/corrosive cleaning products i.e. powders and liquids. If these instructions are not followed, this may invalidate your guarantee in the event of a problem occurring.

Maintenance

The inlet connection contains a filter, should you need to clean the filter, remove the inlet connection to the control box. Pull out the filter and clean under running water.

Replace the filter and inlet pipe.

Troubleshooting

Description	Cause	Treatment
No water out	The battery is exhausted	Change the battery
	Water supply cut off	Check supply
	Dirt in the filter	Clean the filter
	Water pressure to low	Raise the pressure
Water will not turn off	Dirt on the sensor window	Clean the sensor
Too little water flow	Water supply is turned down	Adjust water supply
	The filter is too dirty	Clean the filter
	Water pressure is too low	Raise the pressure
Too much water flow	Water pressure is too high	Adjust pressure
Short cycles of battery	Incorrect batteries	Change to 4 AA Alkaline batteries
The indicator light is not on	The light is broken	Change the light or circuit board
	The circuit board is wet or signal line is wet	Dry out
	The battery is exhausted	Change the battery
	Poor connection of battery	Check battery connections

4